



## HAYLING ISLAND SAILING CLUB HANDHELD RADIO INSTRUCTIONS

### Standard Horizon HX750E & HX751

1. Power ON / OFF	On : Press and hold the Orange On/Off Button until the radio beeps. Off : Press and hold the Orange On/Off Button until the display clears.
2. Channel Selection	Turn the key lock Off (See Note 6). Select channel using the central up and down arrow keys. Turn the key lock back On (See note 6).
3. Transmitting	Press the large Orange PTT button located on the left hand side when talking only. Release the button to listen.
4. Volume Control	Press the VOL button quickly followed by the up or down arrow keys to increase or decrease volume. The volume level will be displayed for a few seconds.
5. Hi / Low Transmit power (User selection)	Press the H/L button. The display will indicate Low (L), Medium (M) or High (H). If nothing is displayed it is on the pre set power for the channel.
6. Key Lock	This will only lock channel selection and is indicated by a key symbol on the bottom right of the screen. To lock press and hold the H/L button until the radio beeps once. To lock press and hold the H/L button until the radio beeps twice
7. Notes	Always wear radio. Keep as dry as possible. Keep Microphone shielded from wind and engine noise.